










# QUICK SETUP – A-Talk USB Phone












10. Click on Account, fill in the details: Information is on the back of the phone eg. Account No: 1777 19\* \*\*\*.  
TelNO is your Account No: 1777 19\* \*\*\*  
**IMPORTANT:** Then click on Apply.



11. Click on proxy tab, in the SIP proxy box.  
Enter IP No: sip.a-talk.com.au  
Port: 5060  
**IMPORTANT:** Then click on Apply.  
Connect the A-Talk USB phone into USB ports at back of computer.  
**DO NOT USE USB PORTS AT FRONT OF PC AS PHONE MAY NOT WORK.**